

SPASTONE™ TOUCHUP INSTRUCTIONS

(The following Paints are required depending on which SpaStone color you are touching up. Order a small quantity of Sherwin-Williams paint.
See Color Codes below for paint specifications.)

Order these colors with the Gray SpaStone

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#200 (Custom Manual Match)
BAC Colorant 02 32 64 128
B1-Black 2 54 1 1
N1-Raw Umber 4 23 - 1
R2-Maroon 2 23 1 -
Y3-Deep Gold 28 35 - 1
W1-White 10 - - -

Note: Used with **Gray stone (BROWN)**

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#600 (Custom Sher-Color Match)
BAC Colorant 02 32 64 128
B1-Black 42 59 1 1
W1-White 6 58 - -

Note: Used with **Gray stone (GRAY)**

Order these colors with the Earth SpaStone

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#100 (Custom Sher-Color Match)
BAC Colorant 02 32 64 128
B1-Black 16 25 1 -
N1-Raw Umber 8 1 1 -
R2-Maroon - 7 1 -
Y3-Deep Gold 4 27 - -

Note: Used with **Earth stone (LT. GRAY)**

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#300 (Custom Sher-Color Match)
BAC Colorant 02 32 64 128
W1-White 12 4 1 1
B1-Black 36 38 - -
L1-Blue 2 16 - -
R2-Maroon 6 5 1 -
Y3-Deep Gold - 62 1 -

Note: Used with **Earth stone (BROWN)**

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#400 (Custom Sher-Color Match)
BAC Colorant 02 32 64 128
W1-White 12 62 - 1
B1-Black 8 62 1 1
R2-Maroon 12 2 - 1
Y3-Deep Gold 22 63 1 -

Note: Used with **Earth stone (RED)**

Sherwin-Williams

Exterior Super Paint Flat
Architectural Latex IFC 8012
#500 (Custom Sher-Color Match)
BAC Colorant 02 32 64 128
W1-White - 63 - 1
B1-Black 38 10 - 1
G2-New Green - 2 1 -
R2-Maroon 2 23 1 -
Y3-Deep Gold 8 22 1 1

Note: Used with **Earth stone (DRK GRAY)**

Materials Required:

- Paint (see first page)
- Soft cloth or Q-tip or small paint brush
- Durham's Water Putty
(use only on damaged or screw hole areas)
- Stirring stick & cup (used with Durham's water putty)



TO FIX A SCUFF MARK



STEP 1

- Determine which color would best cover the scuff mark. Blending colors is also an option.
- Stir the paint well.



STEP 2

- Using a dry cloth or Q-tip, dab the paint onto the scuffed area.
- A paint brush can also be used to apply the paint onto the scuffed area.
- Let paint dry, this will vary depending on temperature.



TO FIX A GASH OR A HOLE



STEP 1

- Determine which color would best cover the hole. Blending colors is also an option.
- Stir the paint well.



STEP 2

- Place a small amount of Durham's water putty into cup.
- Add paint to water putty and mix using stirring stick.
- Mixture should be more of a putty type consistency.



STEP 3

- Place Durham's water putty from cup into hole or gash.



STEP 4

- Use brush to blend putty with stone.
- Once complete, let dry. Drying time will vary depending on temperature.



COMPLETE