I²C Interface Assembly Replacement Instructions

Tools Required:

• Phillips Screwdriver (used to open the equipment compartment and control box.)

I²C Kit Includes:

• I²C Interface Assembly (provides communication between receiver and spa).



I²C Interface Assembly (1116310)

- 1. DISCONNECT ALL POWER to spa.
- 2. Remove the spa equipment compartment door.
- 3. Remove the cover from the control box.



Attach the I^2C Interface Assembly to the Communication Cable from the Receiver.

STEP 5



Attach the other end of I^2C Interface Assembly to the hub inside the control box (8 Port Hub shown).