WATKINS WELLNESS®

Replacement

Filter Bucket Replacement Instructions

STEP 1:

- 1. Locate filter bucket and cut the plumbing lines.
- 2. Make alignment marks for the new filter bucket.





STEP 2:

1. Unscrew and remove filter stand pipe.

NOTE: The new filter bucket has a pre-install standpipe and wall fitting.



STEP 3:

- 1. Remove the ring by carefully prying up using a screw driver.
- 2. Remove the silicone ring.





STEP 4:

- 1. From the inside of the bucket, use a Dremel tool to cut around the entire filter bucket.
- 2. Separate and remove the old filter bucket.





STEP 5:

- 1. Use a sharp chisel to work out the plastic ring.
- 2. Insert a sharp chisel between the shell and the top of the old filter bucket, slowly break the glue joint around the entire opening.





STEP 6:

1. Remove any excess material from the old filter bucket.





1 63509 A (11/19)

Filter Bucket Replacement Instructions

STEP 7:

- 1. Dry fit the new filter bucket and line up with alignment mark.
- 2. Remove and apply a large bead of Devcon to the top





STEP 8:

- Position the filter bucket in place and apply more
 Devcon around the out side of new filter bucket housing.
- 2. Place a block of wood under the filter bucket to hold it in place while the Devcon cures.
- 3. Replace all plumbing lines. **IMPORTANT:** If the 1/4" priming line is not being used, plug it off using Devcon.





STEP 9:

1. Align the ring at the top of the filter bucket and silicone the ring in place.